



User Guide



AM600-CPU1608TP CPU Module

19010638

A03

1

Thank you for purchasing the AM600-CPU1608TP CPU communication module developed and manufactured independently by Inovance.

AM600 series PLC is a medium-sized PLC developed based on CoDeSys. It fully supports IEC61131-3 programming system, EtherCAT site real-time bus, CANopen bus, and cam synchronous movement control. It is provided with unique high-speed I/O interfaces to meet the needs of high-speed applications.

This guide describes the specifications, characteristics and using methods of the AM600-CPU1608TP CPU module. Please read this guide carefully before using to ensure more safe usage. Please refer to the AM600 Series PLC Hardware Manual and the AM600 Series PLC Programming Manual to understand the use of the user program development environment and design method of the user program of the product. You can download the latest materials from [www.inovance.com](http://www.inovance.com).

1. Safety Precautions

Safety information and precautions are identified into two grades: Warning and Caution. Please make sure to operate properly with adequate safety assurance.

**WARNING** Indicates the improper operation which, if not avoided, may cause death or serious injury;

**CAUTION** Indicates the improper operation which, if not avoided, may cause moderate or minor injury, as well as equipment damage.

In some cases, even failure to follow "Cautions" may also lead to serious consequences. Please make sure to follow both warnings and cautions, otherwise, it may cause death or serious injury, as well as product and relevant equipment and system damage.

Please keep this guide well so that it can be read when necessary and forward this guide to the end user.

During control system design

**WARNING**

- Provide a safety circuit outside the PLC so that the control system can still work safely once external power failure or PLC fault occurs.
- Add a fuse or circuit breaker because the module may smoke or catch fire due to long-time overcurrent caused by operation above rated current or load short-circuit.

**CAUTION**

- An emergency stop circuit, a protection circuit, a forward/reverse operation interlocked circuit, and an upper position limit and lower position limit interlocked circuit must be set in the external circuits of the PLC to prevent damage to the machine.
- To ensure safe operation, for the output signals that may cause critical accidents, please design external protection circuit and safety mechanism;
- Once PLC CPU detects abnormality in the system, all outputs may be closed; however, when a fault occurs in the controller circuit, the output may not be under control. Therefore, it is necessary to design an appropriate external control circuit to ensure normal operation;
- If the PLC's output units such as relays or transistors are damaged, the output may fail to switch between ON and OFF states according to the commands;
- The PLC is designed to be used in indoor electrical environment (overvoltage category II). The power supply must have a system-level lightning protection device, assuring that overvoltage due to lightning shock can't be applied to the PLC's power supply input terminals, signal input terminals and output terminals and so forth, so as to avoid damage to the equipment.

During installation

**WARNING**

- Installation must be carried out by the specialists who have received the necessary electrical training and understood enough electrical knowledge.
- Disconnect all external power supplies of the system before module assembly/disassembly and wiring. Failure to do so may result in electric shock, module fault or malfunction.
- Do not use the PLC where there are dust, oil smoke, conductive dust, corrosive or combustible gases, or exposed to high temperature, condensation, wind & rain, or subject to vibration and impact. Electric shock, fire and malfunction may also result in damage or deterioration to the product.
- The PLC is an open-type that must be installed in a control cabinet with lock (cabinet housing must satisfy protection of over IP20). Only the personnel who have the necessary electrical training and experience can open the cabinet.

2

**CAUTION**

- Prevent metal filings and wire ends from dropping into ventilation holes of the PLC during installation. Failure to comply may result in fire, fault and malfunction.
- Ensure that there are no foreign matters on ventilation surface. Failure to comply may result in poor ventilation, which may cause fire, fault and malfunction.
- Ensure the module is connected to the respective connector securely and hook the module firmly. Improper installation may result in malfunction, fault or fall-off.

During wiring

**WARNING**

- Wiring must be carried out by personnel who have the necessary electrical training and experience.
- Disconnect all external power supplies of the system before wiring. Failure to comply may result in electric shock, module fault or malfunction.
- Install the terminal cover attached to the product before power-on or operation after wiring is completed. Failure to comply may result in electric shock.
- Perform good insulation on terminals so that insulation distance between cables will not reduce after cables are connected to terminals. Failure to comply may result in electric shock or damage to the equipment.

**CAUTION**

- Prevent dropping metal filings and wire ends drop into ventilation holes of the PLC at wiring. Failure to comply may result in fire, fault and malfunction.
- The external wiring specification and installation method must comply with local regulations. For details, see the wiring section in this guide.
- To ensure safety of equipment and operator, use cables with sufficient diameter and connect the cables to ground reliably.
- Wire the module correctly after making clear of the connector type. Failure to comply may result in module and external equipment fault.
- Tighten bolts on the terminal block in the specified torque range. If the terminal is not tight, short-circuit, fire or malfunction may be caused. If the terminal is too tight, fall-off, short-circuit, fire or malfunction may be caused.
- If the connector is used to connect with external equipment, perform correct crimping or welding with the tool specified by manufacturer. If connection is in poor contact, short-circuit, fire or malfunction may be caused.
- A label on the top of the module is to prevent foreign matters entering the module. Do not remove the label during wiring. Remember to remove it before system operation, facilitating ventilation.
- Do not bundle control wires, communication wires and power cables together. They must be run with distance of more than 100 mm. Otherwise, noise may result in malfunction.
- Select shielded cable for high-frequency signal input/output in applications with serious interference so as to enhance system anti-interference ability.

During maintenance & inspection

**WARNING**

- Maintenance & inspection must be carried out by personnel who have the necessary electrical training and experience.
- Do not touch the terminals while the power is on. Failure to comply may result in electric shock or malfunction.
- Disconnect all external power supplies of the system before cleaning the module or re-tightening screws on the terminal block or screws of the connector. Failure to comply may result in electric shock.
- Disconnect all external power supplies of the system before removing the module or connecting/removing the communication wirings. Failure to comply may result in electric shock or malfunction.

**CAUTION**

- Get acquainted with the guide and ensure safety before online modification, forcible output, and RUN/STOP operation.
- Disconnect the power supply before installing/removing the extension card.

At disposal

**CAUTION**

- Treat scrapped module as industrial waste. Dispose the battery according to local laws and regulations.

2. Product Information

Model and Nameplate




Figure 1 Description of model and nameplate

Model	Classification	Description	Applicable to
AM600-CPU1608TP	CPU module	10 M program storage space; 20 M data storage space Two RS485; one CANopen/CANlink; one LAN Supporting basic movement control functions; supporting EtherCAT Built-in 16-input 8-output high-speed I/O; Source type output	AM600

External Interface




Figure 2 Diagram 1 of the CPU module interface





Figure 3 Diagram 2 of the CPU module interface

Interface Name	Function
DB9 (CN1)/(Female socket)	Two RS485 interfaces, supporting the MODBUS protocol
DB9 (CN2)/(Female socket)	1. CANopen protocol 2. CANlink protocol
Ethernet port (CN4)	EtherCAT protocol
Ethernet port (CN3)	1. MODBUS TCP 2. Standard Ethernet function 3. System program debugging 4. User program downloading and debugging (only supporting IPv4)
USB	Program downloading and debugging
High-speed I/O	16-point high-speed input 8-point high-speed output
I/O indicator	16-channel input and 8-channel output signal valid indicator
DIP switch	RUN/STOP DIP switch
SD card interface	Stores user programs and data
MFK key	MFK multi-function key
Indicators	Running indicator RUN
	CPU module running error indicator ERR
	System error indicator SF
	Bus error indicator BF
	CANopen/CANlink running indicator CANRUN
LED	CANopen/CANlink error indicator CANERR
LED	Displays alarm messages and MFK key response prompt messages
Local expansion bus interface	Can expand up to 16 I/O modules. The actual number and configuration depend on each module's power consumption Not supporting hot plugging
24 V power input terminal	24 VDC voltage input. The AM600 power supply module must be used for power supply
Grounding switch	Connection switch providing the system internal digital ground and housing ground. It is not connected by default. It is used only on special occasions where the system internal digital ground must be used as a reference plane. You shall not operate it without authorization, otherwise system stability is affected.

3

Interface Name	Function
Communication matching resistance DIP switches	ON indicates matching resistance connection (all OFF by default). 1 and 2 are CAN, 3 and 4 are COM1(RS485), 5 and 6 are COM0 (RS485), 7 and 8 are reserved:



3. General Specifications

Item	Specifications				
Programming mode	IEC 61131-3 programming languages (LD, FBD, IL, ST, SFC, CFC)				
Program execution mode	Complied execution				
User program storage space	10 MBytes				
Flash save space upon power failure	512 KBytes				
SD memory card capacity	Up to 32 G general SD card				
Soft elements and characteristics	Storage Characteristics				
	Element	Name	Quantity	Default	Storage Attributes Changeable
	I	Input relay	64 KWords	Not save	No
	Q	Output relay	64 KWords	Not save	No
	M	Auxiliary relay	240 KWords	-	-
	SM	Special mark	10000 bits	Save	Special use
SD	Special registers	10000 Words	Save	Special use	
Program save mode upon power failure	Flash hold/SD card hold optional (No save upon power failure is performed if power failure occurs at power-on time of smaller than 35s)				
Internal 5 V power output current	1200 mA (rated value)				
Interrupt mode	8-point input interrupt (CPU module high-speed DI), supporting rising edge and falling edge interrupt				

Input Specifications

Item	Specifications
Signal Name	High-speed input (differential or single-ended) (X0-X5) 24 V input
Rated input voltage	24 VDC (+20% to -15%, pulsation within 5%)
Rated input current	7.3 mA (typical) (at 24 VDC)
ON current	More than 5 mA
OFF current	Less than 1.5 mA
Input resistance	3.3 kΩ
Maximum count speed	800 Kpps (two-phase quadruplicated frequency), 200 kHz (single-phase input)
Worst duty ratio at two-phase input	(40% : 60%) to (60% : 40%)
Common mode	Two groups of common terminals -- One common terminal per 10 points

Output Specifications

Item	Specifications
Signal Name	Output (Y0-Y7)
Output polarity	Source type output (high-side output)
Control circuit voltage	5 VDC to 24 VDC
Rated load current	0.1 A / point, 0.5 A / COM
Maximum voltage drop when the module is turned ON	0.2 V (typical value)
Leakage current when the module is turned OFF	Less than 0.1 mA
Output frequency	200 kHz (You must connect an over 12 mA external equivalent load for 200 kHz output.)
Common mode	One common terminal per 4 points

4

- The total extended distance of the high-speed I/O interface extension cable shall be within 3.0 m.
- The single-phase pulse duty ratio must be greater than 40% when high-speed input is in phases A and B.

3. Mechanical Design Reference

Dimensions




Figure 4 Diagram of CPU module dimensions (unit: mm)

4. Electrical Design Reference

Terminal Arrangement




Figure 5 Connection terminal arrangement of the CPU module

Classification	External Wiring *1	CNS Pin No.	Internal Circuit	Signal Name *2	
				Column B	Column A
Input	24VDC	40 39	3.3kΩ	High-speed 24V input (IN0-24V)	High-speed 24V input (IN2-24V)
		38 37		High-speed differential input (IN0-DIFF)	High-speed differential input (IN2-DIFF)
	24VDC	36 35	3.3kΩ	High-speed input common terminal (IN0-COM)	High-speed input common terminal (IN2-COM)
		34 33		High-speed 24V input (IN1-24V)	High-speed 24V input (IN3-24V)
	24VDC	32 31	3.3kΩ	Input common terminal (IN1-DIFF)	High-speed differential input (IN3-DIFF)
		30 29		High-speed input common terminal (IN1-COM)	High-speed input common terminal (IN3-COM)
	24VDC	28 27	3.3kΩ	High-speed 24V input (IN4-24V)	High-speed 24V input (IN5-24V)
		26 25		High-speed differential input (IN4-DIFF)	High-speed differential input (IN5-DIFF)
	24VDC	24 23	3.3kΩ	High-speed input common terminal (IN4-COM)	High-speed input common terminal (IN5-COM)
		22 21		Input common terminal (SS0)	Input common terminal (SS1)
Output	Load	20 19	3.3kΩ	Standard input (IN6)	Standard input (IN7)
		18 17		Standard input (IN8)	Standard input (IN9)
	Load	16 15	3.3kΩ	Standard input (IN4)	Standard input (INB)
		14 13		Standard input (INC)	Standard input (IND)
	Load	12 11	3.3kΩ	Standard input (INE)	Standard input (INF)
		10 9		Output (OUT0)	Output (OUT1)
	Load	8 7	3.3kΩ	Output (OUT2)	Output (OUT3)
		6 5		Output (OUT4)	Output (OUT5)
Load	4 3	3.3kΩ	Output (OUT6)	Output (OUT7)	
	2 1		Output common terminal (COM0)	Output common terminal (COM1)	

\*1 When converting the wiring using an external conversion terminal such as SIRON T024, pay attention to the actual correspondence of the CNS terminal of the CPU module.  
\*2 All 16-channel inputs of the CPU module support high-speed input. The first 6-channel inputs support 24 V single-ended or differential input. The last 10-channel inputs support 24 V single-ended input.

5

Wiring Precautions

- The total extended distance of the high-speed I/O interface extension cable shall be within 3.0 m.
- Do not bundle the extension cable together with power cables (high voltage, large current) which produce strong interference signals. Separate it from other cables and avoid cabling in parallel.
- Select recommended cables and pinboards for connection. It is recommended that shielded cables be used as extension cables to enhance capacity of resisting interference.
- Ensure that the minimum bending radius of cables is greater than 76 mm when laying extension cables. In the case of 76 mm bending radius, malfunction may occur due to performance degradation and cable breaking.

If an SIRON T024-K terminal block is used for interface wiring, see the following figure for the relation between the terminal names and the CNS pin numbers of the CPU module.




Figure 6 Connection of the terminal block

You can purchase the ① high-density extension cable, ② cable connector and ③ terminal block as shown in the figure above from Inovance. See the following for the details.

No.	Order No.	Type	Description
①	15300119	IO extension cable	40PIN FCN-MIL high-density extension cable (50 mm, with two 40PIN FCN connectors)
②	15050180	40PIN FCN connector	Users can use this connector to crimp a cable themselves.
③	15020452	IO extension card (16DI08DO)	40PIN MIL-screw terminal block

5. Communication Connection

Cabling of the CPU Module and Communication Module

- Connection of DB9 connector
- Plug DB9 connector with wire into DB9 plug of module (pay attention to the connector orientation)
- Tighten the screws at both sides of DB9 connector




Figure 7 Diagram of DB9 connector connection

- Disassembly procedures: Loosen the screws at both sides of DB9 connector, hold the plastic part of RJ45 to pull out the connector along a horizontal direction with the module.
- Connection of RJ45 network cable
- Hold and insert the connector with cable into the RJ45 interface of the communication module until a clicking sound is made.




Figure 8 Diagram of network cable connection

- Disassembly procedures: Hold the connector tail mechanism to pull out the connector along a horizontal direction with the module.

- Requirements for securing communication cable

To avoid the influence on the communication cable due to other stresses and ensure the stability of communication, please secure the cable near the equipment before EtherCAT and CANopen communication, as shown in the following figure:






Figure 9 Communication cable must be secured near the equipment

### Connection via EtherCAT bus

- 1) EtherCAT Specifications  
EtherCAT Bus Specifications

Item	Specifications
Communication protocol	EtherCAT protocol
Service supported	CoE (PDO, SDO)
Minimum synchronization period of 6-axis cam	1250 us (typical value)
Maximum synchronization jitter	120 us (typical value)
Synchronization mode	Servo uses a DC-distributed clock. I/O uses I/O synchronization.
Physical layer	100BASE-TX
Baud rate	100 Mbit/s (100Base-TX)
Duplex mode	Full duplex
Topological structure	Linear topological structure
Transmission medium	For the network cable, refer to the "Wiring" section.
Transmission distance	Less than 100 M between two nodes
Number of slaves	Up to 125
EtherCAT frame length	44 to 1498 bytes
Process data	Single Ethernet frame up to 1486 bytes

- 2) Wiring  
The CPU module implements EtherCAT bus communication via a CN4 port. Its requirements for the communication network cable are as follows:




Figure 10 Requirements for EtherCAT network cable preparing

#### Signal pin assignment

Pin	Signal	Signal Direction	Signal Description
1	TD+	Output	Data transfer+
2	TD-	Output	Data transfer-
3	RD+	Input	Data receive+
4	--	--	Disabled
5	--	--	Disabled
6	RD-	Input	Data receive-
7	--	--	Disabled
8	--	--	Disabled

- Length requirements:  
FastEthernet technology demonstrates the cable length between devices shall not exceed 100 m when the EtherCAT bus is used. Otherwise, it will cause signal attenuation, affecting normal communication.
- Technical requirements:  
There is no evidence of short circuit, open circuit, displacement and poor contact during the 100% continuity test. Cables with the following specifications are recommended:

Item	Specifications
Cable type	Elastic crossover cable, S-FTP, enhanced category 5
Standards compliance	EIA/TIA568A, EN50173, ISO/IEC11801 EIA/TI Abulletin TSB, EIA/TIA SB40-A&TSB36
Conductor cross-section	AWG26
Conductor type	Twisted pair
Line pair	4

### Connection via CANopen/CANlink Bus

- 1) Diagram of Networking  
CAN bus topology is shown below. Using shielded twisted cables to connect CAN bus is recommended. Two 120Ω terminal matching resistances are attached to both ends of the bus to prevent signal reflection. Reliable single-point grounding is often used for shielded layers.




Diagram of CANopen/CANlink communication connection

- 2) Communication Interface Description  
CN2 of the CPU module is a CANopen communication interface. The module uses a DB9 connector for data transfer.




Figure 11 CANopen terminal definition on CPU module

- 3) Wiring  
CANopen uses a DB9 connector for data transfer. Below is the definition of DB9 pins:

Diagram	Pin	Definition of signal
9	5	CANL
8	4	
7	3	
6	2	CANH
5	1	
	3	GND

Use shielded twisted cable to connect CAN bus, and attach a 120Ω terminal matching resistance to each end of the bus to prevent signal reflection. Reliable single-point grounding is often used for shield. Do not bundle the cable together with DC cable, high voltage cable, and so forth, so that communication signal will not be interfered.

### Serial Communication Connection via RS485

- 1) Communication Interface Description  
CN1 in the figure shows the RS485 interface. Two RS485 interfaces are supported. Two RS485 channels share the same DB9 interface, as shown in the following figure.




Figure 12 RS485 communication terminal definition on CPU module

Channel	Pin	Definition	Function
COM0 (RS485)	1	RS485-	COM0 RS485 differential pair negative signal
	2	RS485+	COM0 RS485 differential pair positive signal
	5	GND0	COM0 power ground

Channel	Pin	Definition	Function
COM1 (RS485)	6	RS485-	COM1 RS485 differential pair negative signal
	9	RS485+	COM1 RS485 differential pair positive signal
	3	GND1	COM1 power ground

### Connection via Ethernet Monitoring

- 1) Diagram of Networking  
The Ethernet interface of the CPU module can perform point-to-point connection to a computer, HMI, etc. using an Ethernet cable.




Figure 13 Connection of the CPU module to a PC

It can also be connected to a hub or switch using an Ethernet cable and then to other network equipment via the hub or switch to implement multi-point connection.




Figure 14 Connection of the CPU module to other equipment via a switch

- 2) Wiring  
To improve equipment communication reliability, the Ethernet cable must be a category 5 shielded twisted pair with iron case molding line.

### 6. Programming tool downloading

#### Programming Tool Downloading

The user programming software for Inovance AM600 series medium-sized PLC is a free software. You can obtain a software DVD from an Inovance distributor, or download it from the data downloading webpage at Inovance official website [www.inovance.cn](http://www.inovance.cn) or from the Inovance page at [www.gongkong.com](http://www.gongkong.com). You can also download reference data about AM600 series PLC products and applications.

Inovance improves its products and data continuously. It is recommended to update software and refer to any updated and issued reference data to facilitate your application design, if necessary.

#### Programming Environment and Software Installation

Environment Requirements  
Hardware requirements: One desktop PC or portable computer with Windows 7 or later version of the operating system; 2 GB computer RAM contents, over 5 GB remaining space in the hard disk or SSD. It is recommended that the CPU main frequency should be more than 2 GHz, otherwise the running speed is affected.


An LAN network cable can also be used for connection between the PC and the AM600 controller. It is recommended to connect AM600 to the LAN via a router. This allows a greater distance between the PC and the AM600, e.g. performing programming on the AM600 located in the workshop by staying at the office. This also achieves a faster interactive communication rate. Therefore, there must be one idle LAN network interface and one network cable in the local network.

A USB cable can also be used for connection between the PC and the AM600 controller. In this case, one USB cable is needed and a MiniUSB plug must be provided at one end of its cable.


### 7. Operation and Maintenance

#### Run and Stop Operations

- After a program is written to the CPU module, perform the startup and shutdown operations in the following steps.
- After a program is written to the CPU module in STOP state, when running the system:



1. Set the RUN/STOP switch to RUN.
2. Check that the RUN indicator is solid on in green.



3. When you need to stop running, set the RUN/STOP switch to STOP. You can also stop the PLC via upper computer background software.

### 8. Description of Indicators and MFK Key

#### CPU Module Indicators

Indicator Name	Description
RUN indicator	Indicates the current running state (RUN or stop) of the system ON during running, OFF during shutdown
ERRindicator	Indicates any system fault
SF indicator	Expansion bus error indicator
BF indicator	Communication error indicator
CANRUN indicator	Conforms to the CANopen DS303 indicator standard. For details, refer to Chapter 7 of the hardware manual.
CANERRindicator	Conforms to the CANopen DS303 indicator standard. For details, refer to Chapter 7 of the hardware manual.


#### MFK Key Description

The main function of the MFK key is an IP address reset command key of the PLC main module and is valid when the PLC is in STOP state.  
The factory default IP address of the CPU module is 192.168.1.88. If this address is modified, before communication with another PC for networking, communication may fail due to forgetting the last modified IP address. At this moment, set the IP address of the CPU module to the factory default address using the MFK key.

- 1) Press and hold down the MFK key in STOP state until the LED displays I.P.




- 2) If you confirm to reset the IP address, press the MFK key once more, and the LED starts to display a countdown starting from 10, 9, 8...



- 3) When the countdown reaches 0, press the MFK key to finish the reset operation, and the IP address resetting is completed. After the PLC is powered on again, a new IP address will be used.

#### CPU Module LED Display

When the system fails, the fault code information will be displayed through the LED on the CPU. The display mode is "E.r. and fault code" that appear alternatively. Assume that the fault code is 40, the LED display is shown in the following figure:



LED Fault Display Information and Countermeasures:

Local Bus of CPU Module and Diagnosis LED Display of I/O Module	Description	Countermeasures
00	No fault	-
40	Local expansion bus error of the CPU	Check whether connection between local rack modules is normal.
41	Configuration error	Check whether the configurations of local rack modules are consistent with those of the background.
42	Module error	Check whether any fault of local rack modules is detected. Detailed fault information can be viewed on the background interface.

High-speed I/O LED Display	Description	Countermeasures
60	High-speed input error	Detailed fault information can be viewed on the background interface.
61	High-speed input alarm	Detailed fault information can be viewed on the background interface.
62	High-speed output error	Detailed fault information can be viewed on the background interface.
63	High-speed output alarm	Detailed fault information can be viewed on the background interface.

ModBus LED Display	Description	Countermeasures
70	ModBus COM0 error	Detailed fault information can be viewed on the background interface.
80	ModBus COM1 error	Detailed fault information can be viewed on the background interface.
90	ModBusTcp error	Detailed fault information can be viewed on the background interface.

CANopen LED Display	Description	Countermeasures
C0	Slave error	Check whether connection between slave rack modules is normal.
C1	Slave hardware configuration error	Check whether the configurations of slave rack modules are consistent with those of the background.
C2	Slave module error	Check whether any fault of slave rack modules is detected. Detailed fault information can be viewed on the background interface.
CF	CANopen master bus off	Check whether the master closes the CANopen function or check the possibility of master CANopen communication abnormality.

CANlink LED display	Description	Countermeasures
d0	Bus error (BUS OFF)	Check whether the bus connection is normal. Detailed fault information can be viewed via the background.
d1	Address conflict	Check whether address configurations are correct.
d2	No slave online (in the master)	Check whether slave connection is normal or check the possibility of configuration parameter error.
d3	All slave stations disconnected (in the master)	Check all slave connections are normal.
d4	Configuration or command frame error	Check whether bus configuration parameters are correct.

### 9. Module Connection

#### Connecting the Power, CPU and Expansion Modules

Connection between modules is mainly fixed using a module connection interface, fixed lock catch, etc. Take as a sample the connection of the CPU module to the power module.

- 1) Slide the lock catch on the CPU module in the direction as shown in the figure.




Figure 15 Unlocking by sliding a lock catch in a direction

- 2) Connect the connectors on the CPU and power modules fully and tightly.




Figure 16 Connecting the connector on the power module

- 3) Slide the lock catch on the CPU module in the direction as shown in the figure to finish the connection and locking of both modules.




Figure 17 Locking by sliding a lock catch in a direction

#### Connecting the Power, CPU and Expansion Modules

- 1) Pull out downwards all DIN guide rail mounting hooks on the back of the module (as shown in the following local diagram) until a clicking sound is made.




Figure 18 Pulling down hooks on the modules

- 2) Hang the fixed jaw on the upper side of the module to the upper side of the DIN guide rail in direction A as shown in the figure. Press the module group hard in direction B as shown in the figure until it is fully embedded into the guide rail.




Figure 19 Clipping the module into the DIN rail

- 3) After locking the DIN guide rail mounting hooks on the module, embed the module to the DIN guide rail. Press upwards until a clicking sound is made. In addition, tools such as screwdrivers shall be used in the case that no finger can reach the DIN guide rail mounting hooks.




Figure 20 Clipping hooks on the modules in the arrow direction

## INOVANCE Warranty Agreement

- 1) Inovance provides 18-month free warranty to the equipment itself from the date of manufacturing for the failure or damage under normal use conditions.
- 2) Within the warranty period, maintenance will be charged for the damages caused by the following reasons:
  - a. Improper use or repair/modification without prior permission
  - b. Fire, flood, abnormal voltage, other disasters and secondary disasters
  - c. Hardware damage caused by dropping or transportation after procurement
  - d. Improper operations
  - e. Damage out of the equipment (for example, external device factors)
- 3) The maintenance fee is charged according to the latest Maintenance Price List of Inovance.
- 4) If there is any problem during the service, contact Inovance's agent or Inovance directly.
- 5) Inovance reserves the rights for explanation of this agreement.

Suzhou Inovance Technology Co., Ltd.  
Address: No.16, Youxiang Road, Yuexi Town, Wuzhong District, Suzhou 215104, P.R. China  
Website: <http://www.inovance.com>